

For control of a FMS (Forest Motorized System) or BCS (Blind Contract System) by a building automation system an actor is needed. If the home automation system already has relay outputs, then an actor is not needed. Different brands and protocols are possible, in this diagram the basic principle is shown. Used in this diagram is KNX, but can also be AMX, Lutron, Creston etc. Motors have to be connected to earth according to local standards.

