

A = Total Length system(incl. Recess cover plates)

B = Length slot in ceiling

C = Length FMS PLUS track

D = Distance between gap for pulleys

E= Minimum length between walls



FMS PLUS track = A - 125



FMS PLUS Recess profile = A - 157





FMS PLUS Recess strip = A - 207 (one-way draw)

FMS PLUS Recess strip = A - 257 (centreclosing)



 $1\ pcs\ for\ one-way\ draw ({\tt placed\ on\ the\ motorside})$

2 pcs for centreclosing(placed on both sides)

