


WiFi Smart Plug Quick Start Guide



Forest WiFi Smart Plug



LED Indicator		
Flashing Red and Blue		Smart Plug is in Pairing mode after reset
Blue		Smart Plug output is turned off
Purple		Smart Plug output is ON with WiFi connection
Red		Smart plug output is ON without WiFi connection
LED OFF		Smart Plug output is OFF without Wi-Fi Connection

Package contents:

- Forest Smart Plug
- Quick Start Manual

Technical Specifications:

Article Number:	520101952 - EU/FR 520101953 - UK 520101954 - US 520101955 - AU
Working power:	100 - 240V~ AC 50/60Hz
Power consumption:	< 0.3 Watt
Rated Current:	13A – 3000 Watt
Frequency:	2412MHz to 2462MHz
WiFi standard:	IEEE 802.11n20/g/b
Working temperature:	0 – 40°C (32 – 104°F)

Support



Visit www.forestgroup.com/wifisupport for technical support & troubleshooting.

Forest WiFi Smart Plug Installation

- 1. Insert the WiFi Smart Plug in a powered outlet**
- 2. Download and install the Forest Connect App from the Apple App Store or Google Play Store.**




QR scan
OR code



- 3. Connect your mobile phone or tablet to your WiFi network.**

*Note: The WiFi Smart Plug only supports 2.4GHz networks.
During configuration the phone or tablet must be connected to the same WiFi network to which the Smart Plug needs to be connected.*

- 4. Activate the pairing mode on the Smart Plug : Push and hold the button for 6 seconds**



- 5. Launch the Forest Connect app and follow the in- app instructions.**




FAQ & Troubleshooting

1. *What devices can I control using the Forest Smart Plug*

- LED lighting of the Forest DS-XL LED curtainsystem (on/off function)
- Forest Wireless Connector (Art.no: 5201002270).

When the Forest Wireless Connector is connected to the Forest Smart Plug every Forest product with a built-in RF receiver can be opened and closed.

Scan QR code to open the wireless connector manual



Wireless Connector Manual

- Smart Plug is powered on: The wireless connector sends a OPEN signal
- Smart Plug is powered off: The wireless connector sends a CLOSE signal

2. *I don't see any lights on the Smart Plug*

- Make sure the outlet used is powered
- The Smart Plug has no WiFi connection and is turned off
- Reset the Smart Plug: Push and hold the button on the Smart Plug for 6 Seconds. follow the in- app instructions to re- add the device

3. *The Smart Plug won't connect to my WiFi network*

- Reset the Smart Plug – Push and hold the button on the Smart Plug for 6 seconds and repeat the in- app configuration process
- Make sure the right WiFi network was chosen
- Make sure the WiFi password was entered correctly
- Make sure the WiFi Smart Plug is within reach of the WiFi router
- Make sure the WiFi network is 2.4GHz. 5GHz is not supported

4. *I want to hard-reset the Smart Plug to factory settings*

Press and hold the button on the Smart Plug for 6 seconds. The Smart Plug will flash blue and red.

Support



Visit www.forestgroup.com/wifisupport for technical support & troubleshooting.